


Wave Side Chair




Holds up to
300 lb (136.08 kg)

vari®



x2



x2

(M6) Screw 10mm (M6) Washer




x8



(4mm) Hex Key


x1

1




Position the seat with the front edge of the seat in the direction indicated on the sticker underneath the frame.

2



Use the hex key provided to securely tighten 4 screws and washers onto chair body.



 (800) 207-2587



WARNING: To prevent injuries and product failure, do not use this chair for standing, climbing, or leaning. Do not use if the chair is damaged or incorrectly assembled.